

Silent Walk

Description:

- High quality Polyurethane foam underlay.
- Quality underlay for maximum reduction of reflected walking sound
- Suitable for underfloor heating & cooling
- Suitable for installation under laminate and parquet click floors.
- Easy to install



Characteristics:

Properties	Typical result	Test Method
Product code	PGUDLSW7	
Colour	Black / Gold	
Material	Polyurethane	
Thickness	2 mm	EN 823
length	7000 mm	EN 822
width	1000 mm	EN 822
Compression strength (At 0.5mm deformation)	180 kPa	EN 826
Fire protection classification	B _{fl}	EN 13501-1
Thermal conduction resistance	0.01 m ² °K/W	DIN 4108
Impact sound insulation	$\Delta L_w = 18$ dB	ISO 140-8
Walking noise reduction	-29%	IHD 431
Sd-Value	> 75m	DIN 52615

Installation instructions:

1. Lay the underlay in rows with the Damp Proof Membrane (side with Pergo® logo) on the top side, parallel to the laying direction of your Pergo® floor.
2. Install the following row next to the first, as the laying of your floor progresses. Use a damp proof tape to join the underlay together.
(When installing on a wooden subfloor, don't tape the edges).
3. Make sure the underlay fits together tightly (don't leave any gaps)

